

CWD2000 Battery Replacement

Remove power from CWD2000

1. Remove interface cover (manual fig. 42) from right side of units front door.
2. Plug a PS2 Key Board into connector (manual fig. 45) on interface PCB.
3. Open front door and remove rear cover of display / CPU assembly.
NOTE: The ribbon cables may have to be disconnected for cover removal.
4. Remove PC-104 board by unplugging it from it's connectors.
5. Replace battery on PC-104 PCB with a CR2032 solder tabbed battery.
6. Reinsert the PC-104 PCB.
7. Replace rear cover and connectors.
8. Repower the CWD2000
9. During booting cycle, depress Ctrl, Alt & S Keys on PS2 K/B.
10. Depress Alt & Enter (Start Up is selected)
11. Enter (Date & Time is selected)
12. Set the date & time then exit.
13. Unplug K/B replace cover on interface PCB.
14. Close front door.

