



Allow Detector to Cool  
 Remove Filter+Reflector  
 Use Hand Or Pad To Seal

O2 Detector Must Hold Pressure  
 When Pressurized to 10~15" H2O

**Caution:**  
 An Air Leak Will Cause Errors  
 Overtemp = Slow Leak Down  
 Dropped Detector= Fast Leak

<b>DELTA INSTRUMENT LLC</b> Northvale, NJ 07647.	
Job:	Rev: 0
Detector Leak Check Procedure	
Tech Talk Series	Date: 01/04/08